



StartRight Interior Water-Based PVA Drywall Primer

DESCRIPTION: StartRight PVA Latex Primer is an excellent choice for priming new or unsealed drywall, ceilings, non-staining wood, plaster, stone, brick and concrete

PVA-1 FORMULA ANALYSIS

Resin Type-Vinyl Acrylic Latex

Sheen/Type Finish:

1-4 @60° / Primer

Weight per Gallon = 10.98 lbs.

Percent Solids by Weight = 44.0 %

Percent Solids by Volume = 28.0 %

Viscosity Range = 100-105 KU

V.O.C. = Less than 100 g/L

Coverage: 350 sq. ft. per gallon

Product Features

- Seals new drywall
- Soap & water clean-up
- Quick dry time

Colors

PVA-1 White

RECOMMENDED USE

New or unsealed interior drywall, non-staining wood, plaster, brick, stone and concrete surfaces.

THINNING: Use as is.

DRY TIME: Dries in 1/2 hour. Topcoat after 2 hours. Allow 24 hours before sanding. Low temperature or high humidity may increase dry time.

COVERAGE: Average coverage 350 sq. ft. per gallon.

CLEAN UP & STORAGE: Use warm water and soap. Protect unused product from freezing.

DISPOSAL: Full: Give remaining product to neighbors or community organization. Partially full: (If state or local regulations allow) Pour residue into absorbent material. When dry, dispose of in trash for pick up. Empty: This container may be accepted in a recycling program.

APPLICATION METHODS:

- Stir thoroughly before and during use.
- Do not apply over a surface that has not been properly prepared.
- Use product when surface and air temperature are between 50F° – 90F°.
- Do not over spread.
- Use a high quality 3/8 inch nap roller cover or nylon/polyester brush.
- If applying by roller, roll from dry area into the wet using firm crisscrossing strokes. Finish with long ceiling to floor strokes in one direction.
- Paint the ceiling first, then the walls.
- Allow new masonry to cure at least 30 days before coating.

SURFACE PREP

- Remove loose paint, wash off dirt and grease with detergent. Allow to thoroughly dry.
- Scuff-sand and dull glossy surfaces.
- For best results on heavily stained areas, use a coat of StartRight Stain Blocking Primer (SRL-1).
- For drastic color changes or deep, vivid colors, prime with StartRight Dark Color Primer (BC-1).
- Do not use under semi-gloss or gloss paint.