



Exterior Semi-Transparent Oil Deck, Siding & Fence Stain - STOV

DESCRIPTION

Oil Base Semi-Transparent Deck, Siding & Fence Stain for natural or pressure treated wood decks, siding & fences.

STOV FORMULA ANALYSIS

Resin Type-Soya Alkyd/acrylic latex

Sheen/Type Finish:

20-35 @60° / Penetrating Stain

Weight per Gallon = 8.60 lbs.

Percent Solids by Weight = 27.0

Percent Solids by volume = 24.3

Viscosity Range = 25-35 sec.

V.O.C. = Less than 250 g/L

Product Features

- Ideal for natural or pressure-treated wood decks, siding & fences
- Acrylic fortified, scuff & fade resistant coating
- Deep penetrating protection repels water
- Enhances wood grain & texture

COLORS & TINTING

- STOV-7Cedar
- STOV-10 Redwood
- STOV-LT Light Base
- STOV-N-Neutral Base

RECOMMENDED USE: Exterior above ground natural & pressure-treated structures such as decks, shingles, shakes, clapboard, wood siding, rough sawn siding and plywood, wood railings and landscape timbers. Not recommended for trim. Two coats may result in a higher sheen. MPI approved.

DRY TIME, THINNING & TINTING: Dries thoroughly usually within 24 hours. High humidity or low temperatures may increase dry time. (DO NOT THIN). Tinting capability in limited number of colors.

COVERAGE: 100-400 sq. ft. per gallon first coat, 350-450 sq. ft. per gallon second coat depending on the porosity of the wood.

CLEAN UP & DISPOSAL: Wash tools with warm water & soap immediately after application. Properly dispose of all soiled rags. Protect unused portion from freezing. To recycle or properly dispose of paint in your community, call 1-800-CLEANUP (USA only) or visit www.Earth911.org.

APPLICATION:

- Apply only to bare wood surfaces that have been properly prepared and cleaned..
- ONLY ONE COAT IS RECOMMENDED
- Do not apply if rain or dew is expected within 24 hrs or if outside temperature could drop below 50°F
- Do not apply in hot sun.
- Stir thoroughly before and during use.
- Intermix all containers for uniform color.
- Use a premium brush or pad applicator.
- A pump-up sprayer or roller can be used to apply the stain but back brushing with a brush is necessary to get the stain into the wood.
- DO NOT OVER APPLY.
- Spread well, do not puddle or accumulate on wood surface.
- Moving left to right, apply to two or three boards at a time leaving a “wet edge” to prevent lapping.
- Saturate end grain.