



Glass Cleaner

DESCRIPTION

Glass Cleaner cleans and shines with no streaking or hazing.

TV-27 FORMULA:

Percent solids by weight: less than 1.0%

Viscosity: Water thin

Weight per US Gallon: 8.26 +/- 0.1 lbs.

Product Features

- Removes grease
- Keeps surfaces cleaner longer

RECOMMENDED USE: Cleans and shine bare, non-porous surfaces such as windows, appliances, mirrors, chrome, stainless steel, plastic, porcelain, marble, ceramic, vinyl, enamel and Formica.

HELPFUL HINTS: Not recommended for use on unsealed wood or stone or automotive finishes. For product use information, contact your place of purchase.

DISPOSAL: Use up or give away excess product . Contains surfactants. Do not reuse container. Empty container may be recycled or placed in trash.

HANDLING & STORAGE: Do not mix with bleach or any other household cleaning materials. Close container after each use. Store in a cool, dry area. Avoid extreme temperatures. If frozen, thaw and mix before use.

APPLICATION METHODS: Spray uniformly on surface and wipe clean with a lint-free cloth, paper towel or squeegee.

CAUTION

- If cleaning electrical appliances, make sure they are unplugged.
- Avoid contact with eyes and skin. Wearing non-porous gloves is recommended.