



Professional Coatings Good Exterior Flat Finish – ACP-17

DESCRIPTION

Our good quality exterior latex flat finish professional coatings.

ACP-17 FORMULA ANALYSIS

Resin Type: Vinyl Acetate/Acrylic Latex

Sheen/Type Finish:

0-5 @60° / Flat

Weight per Gallon = 10.79 lbs.

Percent Solids by Weight = 44.0 %

Percent Solids by volume = 29.0 %

Viscosity Range = 90-95

V.O.C. = Less than 50 g/L

Product Features

- Good Quality
- Easy soap and water clean-up
- Dries quickly

COLORS AND TINTING

ACP-17 White (may be tinted with up to 2 oz. of universal colorant per gallon.)

RECOMMENDED USE:

Previously painted or primed exterior surfaces including concrete, masonry, vinyl, aluminum and factory primed siding.

RECOMMENDED USE

Previously painted or primed exterior surfaces including properly prepared stucco, brick, concrete and masonry, vinyl, aluminum and factory primed siding.

THINNING: Thin sparingly with water if necessary for spraying.

DRY TIME: Dries to the touch in 2-4 hours. Recoat if necessary after 4 hours. High humidity or low temperature may increase dry time. After 2-4 weeks, cured paint may be cleaned with a mild, non-abrasive liquid detergent. Dry Paint film is mildew resistant.

COVERAGE: 250-400 sq.ft. per gallon depending on the porosity of the surface to be painted.

CLEAN UP: Wash tools with warm water and soap immediately after applying.

Properly Dispose of all soiled rags. To recycle or properly dispose of paint in your community, call 1-800-CLEANUP (USA only)

STORAGE: Protect unused product from freezing.

APPLICATION METHODS

- This paint can be used over latex or oil based paint
- Intermix all containers for color uniformity
- Stir thoroughly before and during use
- Certain colors may require more than one coat
- Do not apply over a surface that has not been properly prepared
- Do not apply if rain or dew is expected within 24 hrs or if outside temperature could drop below 40°
- Use product when surface and air temperature are between 50-90°
- Do not apply in hot sun; follow shade around house
- Do Not over spread
- Use a premium brush or pad applicator
- If spray applied back brushing is recommended to assure adequate penetration into the substrate
- For best performance; apply two coats on new surfaces after priming
- Allow new masonry to cure at least 30 days before coating