



StartRight Interior/Exterior Water-Based Stain Blocking Primer

DESCRIPTION: Interior/Exterior Water-Based Stain Blocking Primer/Sealer great for blocking stains on drywall, paneling, wood, masonry and stucco.

SRL-1 FORMULA ANALYSIS

Resin Type-Acrylic Polymer

Sheen/Type Finish:

1-4 @60° / Primer

Weight per Gallon = 10.82 lbs.

Percent Solids by Weight = 49.0%

Percent Solids by Volume = 34.0 %

Viscosity Range = 95-100 KU

V.O.C. = Less than 100 g/L

Coverage: 300-400 sq. ft. per gallon

Product Features

- Blocking and sealing stains
- Primes surfaces for wall coverings

Colors

SRL-1 White

RECOMMENDED USE: New or unsealed interior drywall, non-staining wood, plaster, brick, stone and concrete surfaces.

THINNING: Use as is.

DRY TIME: Dries to the touch in 1-2 hours. Topcoat after two hours. Allow 24 hours before sanding. Low temperature or high humidity may increase dry time.

COVERAGE: Average coverage 300-400 sq. ft. per gallon.

CLEAN UP: Use warm water and soap.

DISPOSAL: Full: Give remaining product to neighbors or community organization. Partially full: (If state or local regulations allow) Pour residue into absorbent material. When dry, dispose of in trash for pick up. Empty: This container may be accepted in a recycling program.

STORAGE: Protect unused product from freezing.

APPLICATION METHODS:

- Stir thoroughly before and during use.
- Do not apply over a surface that has not been properly prepared.
- Use product when surface and air temperature are between 50°F – 90°F.
- Do not over spread.
- Use a high quality 3/8 inch nap roller cover or nylon/polyester brush.
- If applying by roller, roll from dry area into the wet using firm crisscrossing strokes. Finish with long ceiling to floor strokes in one direction.
- Paint the ceiling first, then the walls.
- Allow new masonry to cure at least 30 days before coating.

SURFACE PREP

- Remove dirt, grease, wax and soap residue.
- Dull glossy areas with sandpaper.
- Patch cracks and holes & sand smooth when dry, then prime.
- New plaster must be properly cured before priming.
- New wood with tannic acid bleed may require StartRight Oil Base Primer/Sealer (SRO-1).